


COMBINAZIONE LED

SIMBOLOGIA:

= LED ACCESO = LED SPENTO


FAULT	LED Fasi	TASTI FUNZIONI			
F01	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F02	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F03	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F04	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F05	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F06	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F07	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F08	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F09	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F10	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F11	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F12	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F13	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F14	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F15	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F16	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F17	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4
F18	LED 4	Tasto 1	Tasto 2	Tasto 3	Tasto 4



ARISTON

INDESIT


FIG. 01



Fault	Key 1	Key 2	Key 3	Key 4	LED 4
01	OFF	OFF	OFF	Flash	OFF
02	OFF	OFF	OFF	OFF	OFF
03	OFF	Flash	Flash	Flash	OFF
04	OFF	Flash	OFF	OFF	OFF
05	Flash	Flash	OFF	Flash	OFF
06	OFF	Flash	Flash	OFF	OFF
07	OFF	Flash	Flash	Flash	OFF
08	Flash	OFF	OFF	OFF	OFF
09	Flash	OFF	OFF	Flash	OFF
10	Flash	OFF	Flash	OFF	OFF
11	Flash	OFF	Flash	Flash	OFF
12	Flash	Flash	OFF	OFF	OFF
13	Flash	Flash	OFF	Flash	OFF
14	Flash	Flash	Flash	OFF	OFF
15	Flash	Flash	Flash	Flash	OFF
16	OFF	OFF	OFF	OFF	Flash
17	OFF	OFF	OFF	Flash	Flash

Tabella Fault LED

FIG. 02



Example Fault F03