# TEST MODE

## ■ Clearing DC offset error detection data (E2PROM data clearing)

| Procedure | Note |
|---|---|
| While pressing and holding [3] key and [6] key, reset-start. | Entering DC offset error display mode. |

| Procedure | Display | Description |
|---|---|---|
| Press and hold the [3] and [6] keys, and reset-start | D C □ □ E R R □ □ | When DC offset error is detected (when either one of capacitors is leaking, or an improper connection or another error is detected) |
| | D C □ □ O K □ □ | When DC offset error is not detected (when none of capacitors leak, no improper connection or other error is detected) |
| 1 | D C 1 □ E R R □ | When improper connection or other DC offset errors are detected. |
| | D C 1 □ O K □ | When improper connection or other DC offset errors are not detected. |
| ■1 | D C 1 □ O K □ | When detecting improper connection or other DC offset errors, clears detection data. (Clear E2PROM) |
| 2 | D C 2 □ 4 □ □ | When detecting capacitor leak, provides information on the number of capacitor leaks. (0~4) |
| ■2 | D C 2 □ 0 □ □ | When detecting capacitor leak, clears the number of capacitor leaks. (Clear E2PROM) |

This mode is cancelled by resetting. (The last screen will not be retained.)

## ■ Security (KDC-W3537A/W3537G/W4037 only)

### • Forced Power ON mode

| Procedure | Note |
|---|---|
| While pressing and holding [B.BOOST] key and [4] key, reset-start. | While "– – –" is displayed, power can be turned ON for only 30 minutes. After 30 minutes, can only be recovered by resetting. |

### • How to register the security code on the "Car Audio Passport" after replacement of the FRONT-END (A1) with E2PROM

| Procedure | Description |
|---|---|
| While pressing and holding [1] key and [3] key, reset-start | Enters the test mode |
| Press the [B.BOOST] key | Enters the MENU mode. |
| Press and hold [▶II] key for 1 second or longer | Enters the security registration mode. |
| [FM] / [AM] / [I◀◀] / [▶▶I] key | Inputs the code. FM: Number up / AM: Number down / I◀◀ ▶▶I Cursor to the left / ▶▶I ▶▶I Cursor to the right |
| Press and hold [▶II] key for 3 seconds or longer | "RE-ENTER" is displayed. |
| [FM] / [AM] / [I◀◀] / [▶▶I] key | Inputs the code again. FM: Number up / AM: Number down / I◀◀ ▶▶I Cursor to the left / ▶▶I ▶▶I Cursor to the right |
| Press and hold [▶II] key for 3 seconds or longer | "APPROVED" is displayed. |
| Reset, momentary power down, ACC OFF, Power OFF, panel removed | Cancels the test mode. |

**Note:** The security code in this model cannot be all-clear.