

**KMX50 / KMX51 / KMX52 / KMX53 / KMX54 / KMX55 / KMX56 / KMX57 /
KMX58 / KMX59 / KMA52 / KMA54**

[DISASSEMBLY INSTRUCTIONS](#)
[SCHEMATIC ILLUSTRATION](#)


Colour variations



- KMX50 - WHITE**
- KMX51 - RED**
- KMX52 - CREAM**
- KMX53 - BLUE**
- KMX54 - BLACK**
- KMX55 - MAROON**
- KMX56 - PINK**
- KMX57 - ORANGE**
- KMX58 - YELLOW**
- KMX59 - BEIGE**
- KMA52 - CREAM - AGA version**
- KMA54 - BLACK - AGA version**

Please note: - On the UK version of KMX50, the pedestal the pedestal body upper are white, whereas on the non-UK version of the KMX50 (and all other models), they are silver.

SLOW SPEED OUTLET COVER ASSEMBLY



- KW710595 - RED**
- KW710594 - WHITE**
- KW710596 - CREAM**
- KW710845 - BLUE**
- KW710597 - BLACK**
- KW710598 - MAROON**
- KW710846 - PINK**
- KW710847 - ORANGE**
- KW710848 - YELLOW**
- KW710849 - BEIGE**
- KW711081 - CREAM - AGA version**

TOP COVER



KW710600 - RED
KW710599 - WHITE
KW710601 - CREAM
KW710850 - BLUE
KW710602 - BLACK
KW710603 - MAROON
KW710851 - PINK
KW710852 - ORANGE
KW710853 - YELLOW
KW710854 - BEIGE
KW711082 - CREAM - AGA version

MOUNT ASSEMBLY



KW710605 - RED
KW710604 - WHITE
KW710606 - CREAM
KW710855 - BLUE
KW710607 - BLACK
KW710608 - MAROON
KW710856 - PINK
KW710857 - ORANGE
KW710858 - YELLOW
KW710859 - BEIGE
KW711083 - CREAM - AGA version



PEDESTAL

KW710609 - SILVER - PRINTED 'KENWOOD'
KW710717 - WHITE - PRINTED 'KENWOOD'
KW711079 - SILVER - PRINTED 'AGA'



KW710675 - LENS - LED



PEDESTAL COVER

KW710610 - PRINTED 'KENWOOD kMix'

KW711080 - PRINTED 'Special edition by Kenwood'



KW710611 - FOOT (PACK 5)



KW710612 - CHROME RING




KW710613 - BASE MOULDING



KW710614 - CONTROL KNOB



KW710615 - CAM AND TORSION SPRING



KW710616 - LIQUID SHEILD



KW 710617- BOWL BAYONET RING




PEDESTAL BODY UPPER

KW710618 - SILVER
KW710718 - WHITE



KW710619 - PEDESTAL COVER UPPER



KW710620 - HEAD RELEASE LEVER



KW710621 - HEADLOCK PIN



KW710622 - MOUNT COUPLER ASSEMBLY



KW710672 - SCREWS - COUPLER (PACK 4)



KW710623 - PIVOT BAR AND PIN




KW710624 - ADJUSTMENT SCREW - PEDESTAL




KW710630 - MOTOR ASSEMBLY - 230V



KW711175 - MOTOR SHROUD - UPPER AND LOWER



KW710625 - BRUSH ASSEMBLY - PAIR



KW710626 - SPEED SENSOR



KW710633 - PLANET HUB ASSEMBLY



KW710634 - PLANET HUB SCREW - SINGLE



KW710635 - PLANET GEAR AND SHAFT ASSEMBLY



KW710636 - PIN - VERTICAL DRIVE SHAFT



KW710637 - SLOW SPEED OUTLET SPIGOT ASSEMBLY
(INCLUDING MAGNETIC STRIP)



KW710638 - PRIMARY GEAR



KW710639 - GEARBOX COVER ASSEMBLY



KW710640 - SHIM AND WASHER SET



KW710641 - SEAL - VERTICAL DRIVE SHAFT (PACK 3)



KW710642 - CIRCLIP - VERTICAL DRIVE SHAFT (PACK



KW710643 - CIRCLIP - SLOW SPEED OUTLET SHAFT (F
5)




KW710644 - SEAL (PACK 3)

* Fits slow speed outlet and top bearing



KW710645 - CAP - TOP BEARING



KW710646 - GASKET - MOTOR



KW710647 - GASKET - GEARBOX



KW710648 - VERTICAL DRIVE SHAFT ASSEMBLY



KW710649 - DRIVE PINION ASSEMBLY



KW710650 - GEAR AND SHAFT ASSEMBLY - SLOW SPEED
OUTLET



KW710651 - WASHER (PACK 5)



KW710673 - SCREWS - MOTOR/GEARBOX (PACK 4)

**KMX50 / KMX51 / KMX52 / KMX53 / KMX54 / KMX55 / KMX56 / KMX57 /
KMX58 / KMX59 / KMA52 / KMA54 - ACCESSORIES**



KW 710652 - BOWL



KW710653 - K-BEATER



KW710654 - WHISK



KW710655 - DOUGH TOOL



KW710656 - SPLASH GUARD



KW710657 - BEATER SHAFT ASSEMBLY