



ORIGINAL	SUPERIOR
	<b>POWER</b>
<b>MUTE</b>	<b>MUTE</b>
<b>MENU</b>	<b>MENU</b>
<b>EXIT</b>	<b>EXIT</b>
<b>1/2/3/4/5</b>	<b>1/2/3/4/5</b>
<b>6/7/8/9/0</b>	<b>6/7/8/9/0</b>
<b>INPUT</b>	<b>AV</b>
<b>-/--</b>	<b>-/--</b>
<b>DISPLAY / INFO</b>	
<b>SIZE</b>	
<b>LANGUAGE</b>	
<b>TV / TXT</b>	
<b>VOL+ / RIGHT</b>	<b>VOL+</b>
<b>VOL- / LEFT</b>	<b>VOL-</b>
<b>CH+ / UP</b>	<b>P+</b>
<b>CH- / DOWN</b>	<b>P-</b>
<b>UP</b>	<b>UP</b>
<b>DOWN</b>	<b>DOWN</b>
<b>LEFT</b>	<b>LEFT</b>
<b>RIGHT</b>	<b>RIGHT</b>
<b>OK</b>	<b>OK</b>
	<b>BACK</b>
<b>SLEEP</b>	<b>SLEEP</b>
<b>NICAM / A2</b>	<b>TV/DTV</b>
<b>INDEX</b>	<b>INFO</b>

ORIGINAL	SUPERIOR
<b>EPG</b>	<b>EPG</b>
<b>FAV</b>	<b>FAV</b>
<b>PICTURE</b>	
<b>HOLD</b>	
<b>RED / TV/RADIO</b>	<b>RED</b>
<b>GREEN</b>	<b>GREEN</b>
<b>YELLOW</b>	<b>YELLOW</b>
<b>BLUE</b>	<b>BLUE</b>
<b>SOUND</b>	<b>SHIFT+MUTE</b>
<b>REVEAL</b>	<b>SHIFT+ </b>
<b>ZOOM</b>	<b>SHIFT+ </b>
<b>DVB</b>	<b>SHIFT+ </b>
<b>TEXT</b>	<b>SHIFT+ </b>
<b>FAV-</b>	<b>SHIFT+LEFT</b>
<b>FAV+</b>	<b>SHIFT+RIGHT</b>
<b>SUBPAGE</b>	<b>SHIFT+DOWN</b>
<b>CANCEL</b>	<b>SHIFT+BACK</b>
<b>SUBTITLE</b>	<b>SHIFT+FAV</b>

COMPATIBLE DEVICES



VISIT OUR WEBSITE TO DISCOVER