


- 2) Insert a screw driver into the slot and open the DVD Tray by sliding the screw driver in the direction shown.



DVDR 33 xx