


SCHEMATIC DIAGRAM

AVR 510/ 310/ 210/ 110/ 5000/ 4000/ 3000/ 2000 MAIN AMP

NO.	DATE	CONTENTS	POS.
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			



AVR 510	AVR 310	AVR 210
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm
8 Ohm	8 Ohm	8 Ohm

OPTION	VERSION	DL / CEA / CE / CB	X	200P
1	0101	0101	X	
2	0102	0102		X
3	0103	0103		
4	0104	0104		
5	0105	0105		
6	0106	0106		
7	0107	0107		
8	0108	0108		
9	0109	0109		
10	0110	0110		
11	0111	0111		
12	0112	0112		
13	0113	0113		
14	0114	0114		
15	0115	0115		
16	0116	0116		
17	0117	0117		
18	0118	0118		
19	0119	0119		
20	0120	0120		

LOC No.	AVR 510	AVR 310	AVR 210	AVR 110	AVR 5000	AVR 4000	AVR 3000	AVR 2000
1	X	X	X	X	X	X	X	X
2	X	X	X	X	X	X	X	X
3	X	X	X	X	X	X	X	X
4	X	X	X	X	X	X	X	X
5	X	X	X	X	X	X	X	X
6	X	X	X	X	X	X	X	X
7	X	X	X	X	X	X	X	X
8	X	X	X	X	X	X	X	X
9	X	X	X	X	X	X	X	X
10	X	X	X	X	X	X	X	X
11	X	X	X	X	X	X	X	X
12	X	X	X	X	X	X	X	X
13	X	X	X	X	X	X	X	X
14	X	X	X	X	X	X	X	X
15	X	X	X	X	X	X	X	X
16	X	X	X	X	X	X	X	X
17	X	X	X	X	X	X	X	X
18	X	X	X	X	X	X	X	X
19	X	X	X	X	X	X	X	X
20	X	X	X	X	X	X	X	X