

# Display NOT reading CompactFlash media

typically, 2 components are observed to be defective; both components can be replaced.  
Component Part Number(s): TR12: **9500BC846** / L1: **9600L13**



