


# ANNEXE D5 - STATUS INDICATORS + OUTPUT FILTER

## SNSA TELECOMMUNICATIONS - 3750VA INVERTER: STATUS INDICATORS + Output Filter



N.B. These indicators are to be mounted at the front panel of the inverter

Figure 4.e