


#### **Definition of terms**

Max :Performance at Maximum compressor frequency

Nominal :Performance at Nominal compressor frequency

Mid :Performance at Medium compressor frequency (80% of Nominal)

Min :Performance at Minimum compressor frequency

 :This icon means injection circuit is active.