


Schéma électrique

GLM 23 et 28
Tirage naturel ou V.M.C.






Die Netzspannung darf erst nach der fertigen Montage des Geräts wieder eingeschaltet werden. Die Anschlüsse sind im Kapitel "Anschlussschaltplan" ersichtlich.



Der Empfänger muss bei ausgeschalteter Netzspannung verdrahtet werden.

2. Verdrahtung prüfen

- Auf einen trockenen und spritzwassergeschützten Standort ist zu achten
- Das Gerät passt auf die meisten handelsüblichen Unterputzdosen oder wird direkt an die Wand montiert



3. Inbetriebnahme des Empfängers

- Wir empfehlen zuerst den Empfänger und dann den Regler/Sender in Betrieb zu nehmen.
- Netz einschalten
 - Taste Reset (= Löschen) für ca. 4 Sekunden drücken, grüne LED blinkt kurz
 - (Löschen der gespeicherten Adresse)
 - Taste Set (= Setzen/ lernen) für ca. 3 Sekunden drücken bis LED grün leuchtet
 - Die Dauer der Lernbereitschaft des Empfängers beträgt max. 25 Minuten. Wird während dieser Zeit kein Signal vom Sender empfangen, Schritte b) und c) nochmals durchführen
 - Regler/Sender montieren und inbetriebsetzen (siehe Inbetriebsetzung Regler/Sender)
 - Wenn der Empfänger vom Regler/Sender ein Signal empfängt, blinkt die LED kurz

en Siting the controller / transmitter

- The controller / transmitter should be mounted in the main living room (wall mounting Fig. C, free standing Fig. G)
- The distance to the receiver should not exceed 20 m or 2 floors
- The unit should be located such that it can measure the room temperature as accurately as possible, without getting affected by direct solar radiation or other heat or refrigeration sources
- The unit should be sited so that it can transmit the signals with as little disturbance as possible. For this reason, the following points should be observed with both the controller / transmitter and receiver:
 - Do not mount on metal surfaces
 - Do not mount near electrical wires, electronic equipment such as PCs, TV sets, microwave equipment, etc.

Commissioning the controller / transmitter

It is recommended to first commission the receiver and then the controller / transmitter.

1. Remove the battery transit tab

As soon as the battery transit tab is removed, the unit starts to operate.

2. Remove the unit from its baseplate

Proceed as shown in Figs. A and B.

3. Configuration with the DIP switches

(Fig. 1)

3.1 Optimum start control, DIP switch 1

Optimum start control brings forward the switch on point P.1 so that the adjusted setpoint will be reached at the required time. The setting depends on the type of control system, that is, on the heat transmission (piping system, radiators), building dynamics (building mass, insulation) and heating output (boiler output, flow temperature). Also refer to Fig. 2!

OFF No effect (standard setting)

¼ h/°C for fast controlled systems

½ h/°C for medium controlled systems